



PowerFleet®

VISION PRO™

SYSTEM SETTINGS

Before You Go Live

CONFIGURING YOUR SYSTEM SETTINGS

**How to set up your Vision Pro™ System
Settings prior to going live.**

CONTENTS

Introduction	1
Getting Ready to Go Live	1
Setting Up Your System Settings	1
Required & Recommended System Settings	4
Checklists	4
Impact Management	4
Shifts	4
Vehicles	4
Vision Pro Online Help	5
Support Options	5
Vision Pro System Administrator	5
PowerFleet Support	5

INTRODUCTION

Before your site is ready to go into Registered ID (Go Live) mode with your PowerFleet Enterprise Vehicle Management System (VMS), you may need to make a few configuration changes to your Vision Pro application. In this document, you will learn how to access and navigate Vision Pro System Settings and understand which settings must be defined prior to going live.


This document may refer to systems settings that may not require configuration because your organization did not purchase certain modules as part of your VMS. If you are the System Administrator/Site Champion at your facility and believe the system is not reflecting the modules included in your license, contact your VMS dealer or assigned PowerFleet Program Management representative.

If you are a Vision Pro user preparing your system for go live and you have questions regarding the modules your organization is licensed for use, contact the site's System Administrator/Site Champion.


GETTING READY TO GO LIVE

SETTING UP YOUR SYSTEM SETTINGS

1. Navigate to the Vision Pro Login page: <https://apps.id-systems.com>.
2. In the VisionPro User Name field, enter your User Name (typically your work email).




3. Click Next.



VisionPro User Name:

Next

4. In the Password field, enter your Password and click Login.



User Name:

Password:

Login

[Forgot Password?](#)

5. On the Home screen, click the Cog  icon's Down-Arrow, located at the top of the page in the Header menu.



PowerFleet

Home Visibility People Groups Assets Messaging Reporting

Settings

Home

Create new Alerts (0) Status Statistics

Refresh Sync

6. From the drop-down menu, select System Settings.



PowerFleet

Home Visibility People Groups Assets Messaging Reporting

Settings

Home

Create new Alerts (0) Status Statistics

Refresh Sync

Roles

System Settings

7. On the System Settings page, you'll notice fields have values assigned during the system's initial setup. As you scroll through the System Settings page, you'll notice that the values for the following settings have been configured:

License

- The License section is populated by read-only fields that correspond with your license key settings and allows you to review which features are enabled (checked boxes) or disabled (unchecked boxes).

Server

- Client Alias fields
- Time Zone

Vehicles

- Languages
- Login Options
- Displays current login usage statistics on the VAC

WAM (if applicable)

- Data
- Location
- Data Rate
- Region

Wi-Fi (if applicable)

- Type
- DNS Name
- IP Address
- Port

The screenshot displays the PowerFleet System Settings interface across four main sections: License, Server, Vehicles, and WAM.

License Section: Shows Software License ID (0000005056A66471DE0000FA009EA18E5DA02B2B01FFFFFF32EDEFFF) and a list of features (e.g., Battery Sense, Impact, OSHA) with checkboxes indicating their status.

Server Section: Shows Client alias (IDSY), Site Code (XXXXX), Facility ID (999999), and CheckSum (4). It also includes Data Archive settings for checklist questions, beacon check-ins, and failure debug data, as well as motion operator and diagnostic errors.


Vehicles Section: Shows New Wireless Upgrade Available (Get New Firmware), Wireless upgrade method (Turned Off), Pending Firmware Version (080304R1), and VAC Jack upgrade (Download Files). It includes sections for Languages (French Canadian, Castilian, English, German, Romanian, Spanish), Primary language (English), and Login Options (Allow login using keypad entry of operator ID, Yes).

WAM Section: Shows Transmission frequency (Data: F902.6, Location: F908.0, Data Rate: 78K).

8. To begin configuring settings, click Edit, located on the lower-right blue task bar.



9. Notice, while in Edit Mode, the options task bar changes to Cancel / Save. Once you've assigned and configured all required and recommended system settings, click Save.



REQUIRED & RECOMMENDED SYSTEM SETTINGS

CHECKLISTS

Prior to the system going live, the following checklist values must be set:

- Safety compliance type
- Safety compliance period

If a safety compliance checklist is set to be dependent on shifts (e.g., OSHA by Shift) then the corresponding shifts must be defined prior to go live. Otherwise, the system will not know when to prompt operators to complete their checklists.

IMPACT MANAGEMENT

Vehicle impact sensors automatically calibrate based on their aggregate data collected over time. Vehicle activity, operator behavior, and site environment are among the variable factors that inform the I.D. Systems intelligent impact management process. Therefore, it is recommended that the default Impact Management settings are not adjusted until the system has been in use for a few weeks after going live and the system has had time to automatically adjust severity levels based on actual vehicle events.

SHIFTS

If you intend to use Vision Pro to analyze performance data by shift, run shift-based reports, set up safety checklists dependent on shifts (e.g., OSHA by Shift) or perform any other system functions that rely on shifts to be defined, you must configure shifts so the system can perform these functions.

NOTE: Shifts may not be configured to overlap and must have a unique name.

VEHICLES

As part of the Go Live event, you will need to set vehicle field, Access Control Mode, to Registered ID.

VISION PRO ONLINE HELP

Knowledge Base articles with additional information and instructions can be found within Vision Pro's Online Help.

- On any Vision Pro page, click the Question Mark  icon to access the Vision Pro Online Help.
- Additional content can be found in the Vision Pro Online Help via the search function. Start all keyword searches with "Vision Pro" for more focused search results.



SUPPORT OPTIONS

VISION PRO SYSTEM ADMINISTRATOR

If you have questions or issues regarding your login credentials, contact your Vision Pro System Administrator who is someone at your organization with advanced access to your Vision Pro software. System Administrators receive training on how to manage the software and its users. They can add new operator badges, update vehicle models, assign checklist profiles and troubleshoot access control issues. They should also know how to verify that your Vision Pro User profile is set up correctly, which often resolves certain login issues.

POWERFLEET SUPPORT

Please contact to our customer support specialists for further assistance.

 (201) 690-7011

 support@powerfleet.com

 9:00 A.M. to 6:00 P.M. Eastern Time (ET) Monday - Friday